ANF IOT sept 2023

Du capteur à la numérisation

Grandeur Physique

Introduction

Signal analogique

Data Acquisition

TNS/
stockage

Confitonnement
Niveaux (tension) et
Fréquences

De l'analogique au numérique

CAN : Convertisseur Analogique Numérique

Caractéristiques principales:

Résolution en nombre de bits

Fréquence d'échantillonnage

La numérisation – (Résolution n bits)

Fig 1

* Cas du codage plein échelle, nécessite un conditionnement du signal avant numérisation

La numérisation – dynamique/résolution considération pratiques -

Ex: capteur de Température LM35

Sensibilité: 10mV/°C

Plage de mesure de température: 0->100°C

Dynamique grandeur physique : 100°C

Dynamique analogique sortie du capteur : 10mV/°C * 100°C = 1V

Si **lecture (numérisation)** capteur avec arduino UNO (exemple)

Arduino UNO (CAN 10bits)

Dynamique analogique : 5V LSB $\leftrightarrow$ 5/1024 $\approx$ 4,9mV

Dynamique numérique: $2^{10}=1024$

La lecture « directe » n'est pas adaptée:

- Une variation d'1°C ne correspond qu'à une variation de 2 bits (sur une dynamique de 1024)
- La plage de variation de tension en sortie du capteur ne correspond qu'à 20% du la plage de lecture de l'arduino UNO $\Rightarrow$ Utilisation d'un conditionneur

Le conditionneur

Banc de test pour test capteurs de luminosité

Le conditionneur

Conditionneur : 2 actions

- amplification $\times 2.5$
- décalage 2.5V

Le conditionneur – dynamique-

Réalisation d'un conditionneur – composants fréquents

La résistance (ohm)

$$U = Ri$$

>>> Permet la limitation de courant <<<

Réalisation d'un conditionneur – composants fréquents: 1 – la résistance

La résistance (ohm)

Le pont diviseur de tension

Utilisation directe
En instrumentation

Exemple de lecture d'une LDR (Light Dependant Resistor)

(autres) Composants dont la résistance varie la température

Utilisation du pont diviseur pour adaptation de niveau

- Utilisation d'un capteur 0 -10V

Réalisation d'un conditionneur – composants fréquemment utilisés: 2- le condensateur

Le condensateur:

$$Z = 1/j(c2*\pi*f)$$

L'impédance dépend de la fréquence,

-> ∞ pour le continu (f= 0Hz)

En pratique

Réalisation d'un conditionneur - composants fréquents

En pratique

Effet de la constante RC (R.C)

Le rapport Signal à Bruit ou (SNR: Signal to Noise Ratio)

Utilisation des connaissances à priori de la **grandeur physique à mesurer**

Du capteur utilisé pour la mesure

Bande de fréquences d'intérêt

Du contexte de la mesure, par exemple présence de source **de bruit connues et caractérisées**

Conditionneur – Adaptation (réduction) du spectre du signal par filtrage

- Role of a filter: Limit, cut, Keep part of the spectrum
- Shapes:
 - LOW PASS
 - HIGH PASS
 - BAND PASS
 - NOTCH
- Specifications
 - Cut off frequency(ies)
 - Attenuation order 1st, 2nd
 - Ripple

Les différents gabarits de filtres

Figure from: http://wps.prenhall.com/chet_paynter_introduct_6/0,5779,426301-,00.html

Les structures de filtre du 1^{er} ordre

LP
$$H(j\omega) = \frac{V_o}{V_i} = \frac{1}{1 + j\omega R_1 C_1}$$

HP
$$H(j\omega) = \frac{V_o}{V_i} = \frac{j\omega R_1 C_1}{1 + j\omega R_1 C_1}$$

BP
$$H(j\omega) = \frac{V_o}{V_i} = \frac{j\omega R_1 C_1}{1 + j\omega R_1 C_1} * \frac{1}{1 + j\omega R_2 C_2}$$

NOTCH
$$H(j\omega) = \frac{V_o}{V_i} = \frac{1 - LC\omega^2}{1 + j(L\omega/R) - LC\omega^2}$$

Filtrage cas concret

Autre composant **très utilisé**: l'Ampli opérationnel

- Infinite open loop gain

LM321

- $A_o = V_{in}/V_{out}$: open loop gain
- $\neq$ from the function (or application) gain
- No feed back
- The output is not controlled it is just defined by the relationship $V_{OUT} = A_o * V_{IN}$

l'Ampli opérationnel

The feed back **provide stability**, the output depends

- on the input value (as in open loop)
- but **also on itself**

Note the that the golbal gain is lower than A_o

MCP6001/1R/1U/2/4

Structure d'un conditionneur

1 MHz, Low-Power Op Amp

Features

- Available in 5-Lead SC-70 and 5-Lead SOT-23 Packages
- Gain Bandwidth Product: 1 MHz (typical)
- Rail-to-Rail Input/Output
- Supply Voltage: 1.8V to 6.0V
- Supply Current: $I_Q = 100 \mu\text{A}$ (typical)
- Phase Margin: 90° (typical)
- Temperature Range:
 - Industrial: -40°C to +85°C
 - Extended: -40°C to +125°C
- Available in Single, Dual and Quad Packages

Applications

- Automotive
- Portable Equipment
- Photodiode Amplifier
- Analog Filters
- Notebooks and PDAs
- Battery-Powered Systems

Design Aids

- SPICE Macro Models
- FilterLab® Software
- Mindi™ Circuit Designer and Analog Simulator
- Microchip Advanced Part Selector (MAPS)
- Analog Demonstration and Evaluation Boards
- Application Notes

Typical Application

Description

The Microchip Technology Inc. MCP6001/2/4 family of operational amplifiers (op amps) is specifically designed for general purpose applications. This family has a 1 MHz Gain Bandwidth Product (GBWP) and 90° phase margin (typical). It also maintains a 45° phase margin (typical) with a 500 pF capacitive load. This family operates from a single-supply voltage as low as 1.8V, while drawing 100 μA (typical) quiescent current. Additionally, the MCP6001/2/4 supports rail-to-rail input and output swing, with a Common-mode input voltage range of $V_{DD} + 300 \text{ mV}$ to $V_{SS} - 300 \text{ mV}$. This family of op amps is designed with Microchip's advanced CMOS process.

The MCP6001/2/4 family is available in the industrial and extended temperature ranges, with a power supply range of 1.8V to 6.0V.

Package Types

- Application Note : AN990 Signal conditioning circuits – an overview

$$V_{OUT} = \left(1 + \frac{R_2}{R_1}\right) * V_{SEN}$$

$$V_{OUT} = -\frac{R_2 \cdot V_{SEN}}{R_1}$$

$$V_{OUT} = -\frac{R_1 \cdot V_{DD}}{R_1 + R_{SEN}}$$

Décalage et amplification

Conditionneur : 2 actions

- amplification $\times 2.5$
- décalage 2.5V

conversion pleine échelle:

Décalage et amplification

MCP6001/1R/1U/2/4

1 MHz, Low-Power Op Amp

Features

- Available in 5-Lead SC-70 and 5-Lead SOT-23 Packages
- Gain Bandwidth Product: 1 MHz (typical)
- Rail-to-Rail Input/Output
- Supply Voltage: 1.8V to 6.0V
- Supply Current: $I_Q = 100 \mu\text{A}$ (typical)
- Phase Margin: 90° (typical)
- Temperature Range:
 - Industrial: -40°C to $+85^\circ\text{C}$
 - Extended: -40°C to $+125^\circ\text{C}$
- Available in Single, Dual and Quad Packages

Applications

- Automotive
- Portable Equipment
- Photodiode Amplifier
- Analog Filters
- Notebooks and PDAs
- Battery-Powered Systems

Design Aids

- SPICE Macro Models

Description

The Microchip Technology Inc. MCP6001/2/4 family of operational amplifiers (op amps) is specifically designed for general purpose applications. This family has a 1 MHz Gain Bandwidth Product (GBWP) and a 90° phase margin (typical). It also maintains a 45° phase margin (typical) with a 500 pF capacitive load. The family operates from a single-supply voltage as low as 1.8V, while drawing 100 μA (typical) quiescent current. Additionally, the MCP6001/2/4 supports rail-to-rail input and output swing, with a Common-mode input voltage range of $V_{DD} + 300 \text{ mV}$ to $V_{SS} - 300 \text{ mV}$. This family of op amps is designed with Microchip's advanced CMOS process.

The MCP6001/2/4 family is available in the industrial and extended temperature ranges, with a power supply range of 1.8V to 6.0V.

Package Types

$$V_{out} = I_{pd} \cdot \frac{R_f}{1 + j\omega R_f * C_f}$$

La numérisation – Fréquence d'échantillonnage -

La fréquence d'échantillonnage (F_s) est déterminée en fonction des caractéristiques fréquentielles du signal à numériser.

$F_s > 2 * \text{Fréquence maximale du signal}$

Cas du LM35

Figure 4. Thermal Response In Stirred Oil Bath

Fréquence d'échantillonnage – Théorème de Shannon

Practically:

Often 1st order LP filter

Shannon condition for frequency issues

Erreur: c'est une variable aléatoire avec une moyenne (m ou μ) et un écart type σ

Écart de la moyenne à la mesure : c'est l'erreur systématique

Ecart type: fluctuation d'une mesure à l'autre

Intervalle de confiance: c'est l'intervalle où la valeur à $n\%$ de chance de se trouver

Incertitude des mesures

Quand on effectue un mesurage... au rang i

$$X_i = M + E_i$$

X_i : i ème mesure

E_i incertitude de mesure liée à X_i

Ces erreurs sont aléatoires on dit que X_i et E_i sont des variables **aléatoires continues**

Pour « compenser » E , on fait plusieurs mesurages pour ensuite en général en faire la moyenne

On dispose donc de

→ n analyses du même échantillon
 n échantillons