



Systemes d'Informations et Calcul
pour le Phénotypage Animal

➤ Le projet SICPA_IOT

➤ Contexte et objectifs

1

Directive 2010/63/UE du Parlement Européen relative à la protection des animaux utilisés à des fins scientifiques.

-> Contrôler et enregistrer les données d'environnement (température, humidité, lumière, qualité de l'air, ...).

2


Intérêt scientifique. Mieux contrôler et intégrer l'impact des données d'ambiances sur les résultats des expérimentations.

->


Création d'une infrastructure LoRa et d'un stockage type time série.

➤ Réseau de capteurs

Collecter des données de différents capteurs de différentes façon en utilisant différentes technologies



➤ Réseau de capteurs et LoRa



➤ Des capteurs LoRa

Capteurs



Elsys ERS

Température
Humidité
Lumière
Son
CO2



Axioma

Consommation d'eau



MCF88

Courant
Puissance
Pilotage à distance



RF Track

GPS

ESP32



This board with weld pin header



Adeunis FTD

Testeur de réseau

➤ Des capteurs LoRa

Passerelles



Rak Wireless

Wifi
Gsm
Gps
IP67




Rak Wireless

Raspberry PI
Wifi
Gps

Mikrotik

Wifi
IP56



- Org. dashboard
- Org. users
- Org. API keys
- Service-profiles
- Device-profiles
- Gateways
- Applications

 DELETE

GATEWAY DETAILS GATEWAY CONFIGURATION CERTIFICATE GATEWAY DISCOVERY LIVE LORAWAN FRAMES

Gateway ID	3530362033004300
Altitude	0 meters
GPS coordinates	47.058516345778, 2.510789107827858
Last seen at	Mar 4, 2022 9:08 AM




Heatmap visualization showing the number of cases per day for each country from Feb 2 to Mar 4. The y-axis lists countries with their total case counts. The x-axis shows dates. Darker blue indicates higher case counts. The United States shows a significant peak in late February and early March.




The line chart displays the daily number of COVID-19 cases in the Netherlands. The y-axis represents the number of cases, ranging from 0 to 140 in increments of 20. The x-axis shows dates from February 2 to March 4. The data points are as follows:

Date	Number of Cases
Feb 2	135
Feb 3	135
Feb 4	138
Feb 5	135
Feb 6	138
Feb 7	138
Feb 8	140
Feb 9	138
Feb 10	135
Feb 11	138
Feb 12	138
Feb 13	140
Feb 14	125
Feb 15	138
Feb 16	140
Feb 17	138
Feb 18	138
Feb 19	140
Feb 20	135
Feb 21	135
Feb 22	138
Feb 23	140
Feb 24	100
Feb 25	65
Feb 26	138
Feb 27	140
Feb 28	138
Mar 1	138
Mar 2	138
Mar 3	140
Mar 4	50


➤ Chaîne de traitement de la donnée



➤ MQTT (Mosquitto)



➤ Telegraf (Stack InfluxData)



Telegraf : <https://www.influxdata.com/time-series-platform/telegraf/>

Aggregators : <https://docs.influxdata.com/telegraf/v1.21/plugins/#aggregator-plugins>

Inputs : <https://docs.influxdata.com/telegraf/v1.21/plugins/#input-plugins>

Outputs : <https://docs.influxdata.com/telegraf/v1.21/plugins/#output-plugins>

Processors : <https://docs.influxdata.com/telegraf/v1.21/plugins/#processor-plugins>



INRAE




Systèmes d'Informations et Calcul
pour le Phénotypage Animal

SICPA_IOT / ANF-IOT CNRS/INRAE / du 24 au 28 octobre 2022

JF Bompa / T Heirman / F Laperruque

➤ InfluxDB (Stack InfluxData)



INRAE



Systèmes d'Informations et Calcul
pour le Phénotypage Animal

SICPA_IOT / ANF-IOT CNRS/INRAE / du 24 au 28 octobre 2022

JF Bompas / T Heirman / F Laperruque


InfluxDB : <https://www.influxdata.com/products/influxdb-overview/>

Line protocol : https://docs.influxdata.com/influxdb/v1.8/write_protocols/line_protocol_tutorial

InfluxQL : https://docs.influxdata.com/influxdb/v1.8/query_language/

➤ Grafana





Query 3 Transform 0 Alert 0

Data source InfluxDB- Query options MD = auto = 1940 Interval = 5m Query inspector

A (InfluxDB-)

FROM

rp_

device_rak7204-ea87

WHERE

+

SELECT

field(temperature)

mean()

+

GROUP BY

time(15m)

fill(null)

+

TIMEZONE

(optional)

ORDER BY TIME

ascending

▼

LIMIT

(optional)

SLIMIT

(optional)

FORMAT AS

Time series

▼

ALIAS

temperature

B (InfluxDB-)

FROM

rp_

device_rak7204-ea87

WHERE

+

SELECT

field(humidity)

mean()

+

GROUP BY

time(15m)

fill(null)

+

TIMEZONE

(optional)

ORDER BY TIME

ascending

▼

LIMIT

(optional)

SLIMIT

(optional)

FORMAT AS

Time series

▼

ALIAS

Humidity

Search options

All Overrides

Panel options

Title

Temp C°/Humid %/Presson Pa RAK-7204-EA87

Description

Transparent background

Panel links

Repeat options

Display

Series overrides

Axes

Left Y

Show

Unit

Scale

Y-Min

Y-Max

Decimals

Label

Right Y

Show

Unit

Scale

Y-Min

Y-Max

Decimals

Label

Y-Axes

Align Y-Axes

➤ Et ensuite ?

